

“E-Z 20” Trotline

This “E-Z 20” trotline kit includes 20 hooks and 150 feet of line.

This 150 feet of line is enough to allow 2' for each drop (staging) and 20 hooks at 5' apart.

Remember the fish don't care if the hooks are 5' apart of 4' apart, so don't spend too much time trying to get the drops exactly 5' apart. Some states have regulations on putting the hooks closer than 4', so you may want to check with your local wild life agent about this and other trotline regulations.

The first step is to put the drops in the line. This is done by pulling about 6' of line off the roll. (For most people this will be about how far they can reach when both arms are extended.) Pulling off 6' of line, will be the point where the hook will be attached. Double the line back about 1' and put an overhand knot in the line. This will use 1' of the line already measured and 1' of line beyond the point you measured. Repeat this process for the rest of the line. Once the drops have been placed in the line, put on the hooks. A simple half hitch will work, but it is better to put on a locking half hitch as shown below.



“E-Z 20” Trotline

This “E-Z 20” trotline kit includes 20 hooks and 150 feet of line.

This 150 feet of line is enough to allow 2' for each drop (staging) and 20 hooks at 5' apart.

Remember the fish don't care if the hooks are 5' apart of 4' apart, so don't spend too much time trying to get the drops exactly 5' apart. Some states have regulations on putting the hooks closer than 4', so you may want to check with your local wild life agent about this and other trotline regulations.

The first step is to put the drops in the line. This is done by pulling about 6' of line off the roll. (For most people this will be about how far they can reach when both arms are extended.) Pulling off 6' of line, will be the point where the hook will be attached. Double the line back about 1' and put an overhand knot in the line. This will use 1' of the line already measured and 1' of line beyond the point you measured. Repeat this process for the rest of the line. Once the drops have been placed in the line, put on the hooks. A simple half hitch will work, but it is better to put on a locking half hitch as shown below.

